

# Chapter 1

## Computer Abstractions and Technology

### The Computer Revolution

§1.1 Introduction


- Progress in computer technology
  - Underpinned by Moore's Law
- Makes novel applications feasible
  - Computers in automobiles
  - Cell phones
  - Human genome project
  - World Wide Web
  - Search Engines
- Computers are pervasive

# Classes of Computers

- Desktop computers
  - General purpose, variety of software
  - Subject to cost/performance tradeoff
- Server computers
  - Network based
  - High capacity, performance, reliability
  - Range from small servers to building sized
- Embedded computers
  - Hidden as components of systems
  - Stringent power/performance/cost constraints



# The Processor Market




# Understanding Performance

- Algorithm
  - Determines number of operations executed
- Programming language, compiler, architecture
  - Determine number of machine instructions executed per operation
- Processor and memory system
  - Determine how fast instructions are executed
- I/O system (including OS)
  - Determines how fast I/O operations are executed



# Below Your Program




- Application software
  - Written in high-level language
- System software
  - Compiler: translates HLL code to machine code
  - Operating System: service code
    - Handling input/output
    - Managing memory and storage
    - Scheduling tasks & sharing resources
- Hardware
  - Processor, memory, I/O controllers




# Levels of Program Code

- High-level language
  - Level of abstraction closer to problem domain
  - Provides for productivity and portability
- Assembly language
  - Textual representation of instructions
- Hardware representation
  - Binary digits (bits)
  - Encoded instructions and data



# Components of a Computer

## The BIG Picture




- Same components for all kinds of computer
  - Desktop, server, embedded
- Input/output includes
  - User-interface devices
    - Display, keyboard, mouse
  - Storage devices
    - Hard disk, CD/DVD, flash
  - Network adapters
    - For communicating with other computers


§ 1.3 Under the Covers



# Opening the Box



Hard drive Processor Fan with cover Spot for memory DIMMs Spot for battery Motherboard Fan with cover DVD drive cover



# Inside the Processor (CPU)

- Datapath: performs operations on data
- Control: commands the datapath, memory, and the I/O devices according to the program instructions.
- Cache memory
  - Small fast SRAM memory for immediate access to data
  - Acts as buffer to the DRAM memory



# Abstractions


## The BIG Picture

- Abstraction helps us deal with complexity
  - Hide lower-level detail
- Instruction set architecture (ISA)
  - The hardware/software interface
- Implementation
  - The details underlying the interface




# A Safe Place for Data

- Volatile main memory
  - Loses instructions and data when power off
- Non-volatile secondary memory
  - Magnetic disk
  - Flash memory
  - Optical disk (CDROM, DVD)




# Networks

- Communication and resource sharing
- Local area network (LAN): Ethernet
  - Within a building
- Wide area network (WAN: the Internet)
- Wireless network: WiFi, Bluetooth



# Technology Trends

- Electronics technology continues to evolve
  - Increased capacity and performance
  - Reduced cost



DRAM capacity

Year	Technology	Relative performance/cost
1951	Vacuum tube	1
1965	Transistor	35
1975	Integrated circuit (IC)	900
1995	Very large scale IC (VLSI)	2,400,000
2005	Ultra large scale IC	6,200,000,000



# Response Time and Throughput

- Response time
  - How long it takes to do a task
- Throughput
  - Total work done per unit time
    - e.g., tasks/transactions/... per hour
- How are response time and throughput affected by
  - Replacing the processor with a faster version?
  - Adding more processors?



# Relative Performance

- Define Performance = 1/Execution Time
- “X is  $n$  time faster than Y”
  - $\text{Performance}_X / \text{Performance}_Y$   
=  $\text{Execution time}_Y / \text{Execution time}_X = n$
- Example: time taken to run a program
  - 10s on A, 15s on B
  - $\text{Execution Time}_B / \text{Execution Time}_A$   
=  $15\text{s} / 10\text{s} = 1.5$
  - So A is 1.5 times faster than B






# Measuring Execution Time

- Elapsed time
  - Total response time, including all aspects
    - Processing, I/O, OS overhead, idle time
  - Determines system performance
- CPU time
  - Time spent processing a given job
    - Discounts I/O time, other jobs' shares
  - Comprises user CPU time and system CPU time
  - Different programs are affected differently by CPU and system performance



# CPU Clocking

- Operation of digital hardware governed by a constant-rate clock



- Clock period: duration of a clock cycle
  - e.g.,  $250\text{ps} = 0.25\text{ns} = 250 \times 10^{-12}\text{s}$
- Clock frequency (rate): cycles per second
  - e.g.,  $4.0\text{GHz} = 4000\text{MHz} = 4.0 \times 10^9\text{Hz}$



# CPU Time

$$\begin{aligned}\text{CPU Time} &= \text{CPU Clock Cycles} \times \text{Clock Cycle Time} \\ &= \frac{\text{CPU Clock Cycles}}{\text{Clock Rate}}\end{aligned}$$

- Performance improved by
  - Reducing number of clock cycles
  - Increasing clock rate
  - Hardware designer must often trade off clock rate against cycle count



## Example

Our favorite program runs in 10 sec. on computer A, which has a 2 GHz clock. We are trying to help a computer designer build a computer B which will run this program in 6 seconds. The designer has determined that a substantial increase in the clock rate is possible but this increase will affect the rest of the CPU design, causing computer B to require 1.2 times as many clock cycles as computer A for this program. What clock rate should we tell the designer to target



# CPU Time Example

- Computer A: 2GHz clock, 10s CPU time
- Designing Computer B
  - Aim for 6s CPU time
  - Can do faster clock, but causes  $1.2 \times$  clock cycles
- How fast must Computer B clock be?



# CPU Time Example

- Computer A: 2GHz clock, 10s CPU time
- Designing Computer B
  - Aim for 6s CPU time
  - Can do faster clock, but causes  $1.2 \times$  clock cycles
- How fast must Computer B clock be?

$$\text{Clock Rate}_B = \frac{\text{Clock Cycles}_B}{\text{CPU Time}_B} = \frac{1.2 \times \text{Clock Cycles}_A}{6\text{s}}$$

$$\begin{aligned}\text{Clock Cycles}_A &= \text{CPU Time}_A \times \text{Clock Rate}_A \\ &= 10\text{s} \times 2\text{GHz} = 20 \times 10^9\end{aligned}$$

$$\text{Clock Rate}_B = \frac{1.2 \times 20 \times 10^9}{6\text{s}} = \frac{24 \times 10^9}{6\text{s}} = 4\text{GHz}$$



# Instruction Count and CPI

$$\begin{aligned}\text{Clock Cycles} &= \text{Instruction Count} \times \text{Cycles per Instruction} \\ \text{CPU Time} &= \text{Instruction Count} \times \text{CPI} \times \text{Clock Cycle Time} \\ &= \frac{\text{Instruction Count} \times \text{CPI}}{\text{Clock Rate}}\end{aligned}$$

- Instruction Count for a program
  - Determined by program, ISA and compiler
- Average cycles per instruction
  - Determined by CPU hardware
  - If different instructions have different CPI
    - Average CPI affected by instruction mix



## CPI Example

- Computer A: Cycle Time = 250ps, CPI = 2.0
- Computer B: Cycle Time = 500ps, CPI = 1.2
- Same ISA
- Which is faster, and by how much?



## CPI Example

- Computer A: Cycle Time = 250ps, CPI = 2.0
- Computer B: Cycle Time = 500ps, CPI = 1.2
- Same ISA
- Which is faster, and by how much?

$$\text{CPU Time}_A = \text{Instruction Count} \times \text{CPI}_A \times \text{Cycle Time}_A$$

$$= 1 \times 2.0 \times 250\text{ps} = 1 \times 500\text{ps} \quad \leftarrow \text{A is faster...}$$

$$\text{CPU Time}_B = \text{Instruction Count} \times \text{CPI}_B \times \text{Cycle Time}_B$$

$$= 1 \times 1.2 \times 500\text{ps} = 1 \times 600\text{ps}$$

$$\frac{\text{CPU Time}_B}{\text{CPU Time}_A} = \frac{1 \times 600\text{ps}}{1 \times 500\text{ps}} = 1.2 \quad \leftarrow \text{...by this much}$$



## CPI in More Detail

- If different instruction classes take different numbers of cycles

$$\text{Clock Cycles} = \sum_{i=1}^n (\text{CPI}_i \times \text{Instruction Count}_i)$$

- Weighted average CPI

$$\text{CPI} = \frac{\text{Clock Cycles}}{\text{Instruction Count}} = \sum_{i=1}^n \left( \text{CPI}_i \times \frac{\text{Instruction Count}_i}{\text{Instruction Count}} \right)$$

Relative frequency



# CPI Example

- Alternative compiled code sequences using instructions in classes A, B, C

Class	A	B	C
CPI for class	1	2	3
IC in sequence 1	2	1	2
IC in sequence 2	4	1	1

- Sequence 1: IC = 5
  - Clock Cycles  
 $= 2 \times 1 + 1 \times 2 + 2 \times 3$   
 $= 10$
  - Avg. CPI =  $10/5 = 2.0$
- Sequence 2: IC = 6
  - Clock Cycles  
 $= 4 \times 1 + 1 \times 2 + 1 \times 3$   
 $= 9$
  - Avg. CPI =  $9/6 = 1.5$



# Performance Summary


## The BIG Picture

$$\text{CPU Time} = \frac{\text{Instructions}}{\text{Program}} \times \frac{\text{Clock cycles}}{\text{Instruction}} \times \frac{\text{Seconds}}{\text{Clock cycle}}$$

- Performance depends on
  - Algorithm: affects IC, CPI
  - Programming language: affects IC, CPI
  - Compiler: affects IC, CPI
  - Instruction set architecture: affects IC, CPI,  $T_c$



# Uniprocessor Performance



Constrained by power, instruction-level parallelism, memory latency



# Multiprocessors

- Multicore microprocessors
  - More than one processor per chip
- Requires explicitly parallel programming
  - Compare with instruction level parallelism
    - Hardware executes multiple instructions at once
    - Hidden from the programmer
  - Hard to do
    - Programming for performance
    - Load balancing
    - Optimizing communication and synchronization



## Amdahl's Law

- Improving an aspect of a computer and expecting a proportional improvement in overall performance

$$T_{\text{improved}} = \frac{T_{\text{affected}}}{\text{improvement factor}} + T_{\text{unaffected}}$$



## Amdahl's Law

- A program runs in 100 s on a computer, with multiply operations responsible for 80 s of this time. How much do I have to improve the speed of multiplication if I want my program to run five times faster?





## Amdahl's Law

- A program runs in 100 s on a computer, with multiply operations responsible for 80 s of this time. How much do I have to improve the speed of multiplication if I want my program to run five times faster?
- multiply accounts for 80s/100s
  - How much improvement in multiply performance to get 5× overall?

$$20 = \frac{80}{n} + 20$$

■ Can't be done!

- Corollary: make the common case fast



## Fallacy: Low Power at Idle

- X4 power benchmark
  - At 100% load: 295W
  - At 50% load: 246W (83%)
  - At 10% load: 180W (61%)
- Google data center
  - Mostly operates at 10% – 50% load
  - At 100% load less than 1% of the time
- Consider designing processors to make power proportional to load



## Pitfall: MIPS as a Performance Metric

- MIPS: Millions of Instructions Per Second
  - Doesn't account for
    - Differences in ISAs between computers
    - Differences in complexity between instructions

$$\begin{aligned} \text{MIPS} &= \frac{\text{Instruction count}}{\text{Execution time} \times 10^6} \\ &= \frac{\text{Instruction count}}{\frac{\text{Instruction count} \times \text{CPI}}{\text{Clock rate}} \times 10^6} = \frac{\text{Clock rate}}{\text{CPI} \times 10^6} \end{aligned}$$

- CPI varies between programs on a given CPU



## Example

- Performance measurements for a program

Measurement	Computer A	Computer B
Instruction count	10 billion	8 billion
Clock rate	4 GHz	4 GHz
CPI	1.0	1.1

- Which computer has the higher MIPS rating?
- Which computer is faster?



# Concluding Remarks

- Cost/performance is improving
  - Due to underlying technology development
- Hierarchical layers of abstraction
  - In both hardware and software
- Instruction set architecture
  - The hardware/software interface
- Execution time: the best performance measure
- Power is a limiting factor
  - Use parallelism to improve performance

